Rollesby Road, Hardwick Trading Estate,
King's Lynn. Norfolk. PE30 4JS

Telephone: +44 (0)1553 776 835
Email: info@reevewood.com
Website: www.reevewood.com

How to maintain your Reeve Hardwood Floor

To keep your floor happy and healthy - here is how to do it.

What NOT to do

- Never use maintenance products that are not recommended by Reeve Wood.
- Never use maintenance products that are intended for a lacquer finish.
- Never use chemical cleaning products that contain ammonia, vinegar, turpentine, etc.
- Never use maintenance products intended for a wax finish.
- Never drag heavy furniture or objects. This may result in deep scratches in your floor.
- Never use a hard brush to sweep your floor – only a soft brush.
- Never use a metal dustpan to sweep up dust/dirt – they scratch.

A few basics

- Install doormats at all entrances – grit is the enemy of all hardwood floors.
- Attach special felt pads to the feet of tables, chairs and sofas.
- Stiletto heels will damage all hardwood floors.

Daily / Regular maintenance

- The best protection against this is to vacuum your floor regularly or sweep with a soft brush.
- Wash the floor with a damp cloth or mop using warm water and Reeve Soap – use 3 caps per 5 Litres of water.
- Reeve Soap cleans the floor and adds protection.

Cleaning after accidents and spills

- Clean up spills and accidents with a damp cloth and leave to dry.
- If there is a mark after the floor has dried use either Reeve Soap or Reeve Intensive Cleaner on a cloth. Then wipe clean with a damp cloth.
- Allow the floor/spot to dry for 20 minutes before walking over it again.

Where to get Reeve Cleaning Products and Reeve Oil https://www.reevewood.com/shop/

Rollesby Road, Hardwick Trading Estate,
King's Lynn. Norfolk. PE30 4JS

Telephone: +44 (0)1553 776 835
Email: info@reevewood.com
Website: www.reevewood.com

Reeve Soap

- For regular cleaning - weekly, every two weeks or monthly.
- Add 150ml or 4 cap fulls to half a bucket of water - 5 Litres.
- Wash the floor rubbing it dry and not puddling.
- Allow the floor to dry for at least 20 minutes.
- Read the full instructions on the package before use.

Reeve Maintenance Oil

- For periodic maintenance and nourishment of the finish.
- Before applying clean the floor with the Intensive Cleaner.
- Remove all dirt and grit before applying.

Worn spots and Scratches

- First use a slightly damp cloth with Intensive Cleaner.
- Use Maintenance Oil to repair the worn spot or scratch.
- Allow to dry overnight.

Reeve Intensive Cleaner

- Use for intensive cleaning before applying Maintenance Oil
- Add 65ml of Intensive Cleaner to 5 litres of lukewarm water.
- Wash the floor with a mop that is thoroughly wrung out.
- Regularly rinse the mop clean during use.

Reeve Coloured Oil

- One coat for use on flooring, veneers and repairs.
- Can be used on any wood material for bespoke joinery, flooring, wall panelling, cladding, stairs and doors.
- 2 part pack – 250ml oil / 50ml activator hardener.
- Covers 12m2 – Mix only what you need.

Where to get Reeve Cleaning Products and Reeve Oil https://www.reevewood.com/shop/